

## To run the Osprey

1. Turn off the TCS power.
2. Via the A/B switch, switch the serial ports to the **B** setting.
3. Swap the Osprey QBUS card which is in a dummy slot (**Slot2 E, F**) with the QBUS extender card (**Slot1 C, D**).
4. Turn on the TCS power.
5. If the T5 machine is off, login under administrator with the password **irtftcs!**
6. Click the osprey icon on the desktop. Osprey/TCS will then boot.